


# CSW and Ambio super power battery locks

Instructions for tamper resistant battery compartment on the IFCSW91 and AM598 models

## To lock the battery door:



Insert tool straight into battery door lock.



Slide lock to the left.




Indication mark shows “lock” position – white dot appears.

## to unlock the battery door (to replace the battery):



Insert tool straight into battery door lock.



Slide lock to the right.



Open the battery door completely to replace the battery.

Audiologist contact details: